



POLYWOOD

Assembly Instructions



PT172, PT172NH Park 72" Picnic Table



20-year warranty

View our full warranty:
polywoodoutdoor.com/warranty



Having trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at hello@polywoodoutdoor.com or (833) 665-6300



Cleaning tips

For a Quick Clean:

Simply wipe down with soap and water.

For a Deep Clean:

Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft-bristle brush. Hose down to rinse.

Thank You

Thank you for choosing POLYWOOD!
We hope our furniture helps create a gathering place for you and your loved ones to enjoy for many years to come!



Reach Out

Let us know how we're doing:
hello@polywoodoutdoor.com
(833) 665-6300



Stay Connected

Be the first to hear about new products, giveaways, and more by signing up for our email list: polywoodoutdoor.com/subscribe



Watch & Learn

For assembly tips and videos visit:
polywoodoutdoor.com/assembly

Share your space

We love to see where our furniture ends up — snap a pic and tag it on Instagram or Facebook for your chance to be featured on our social channels!
#polywood #rethinkoutdoor



facebook.com/polywoodoutdoor




[@POLYWOOD](https://instagram.com/POLYWOOD)



pinterest.com/polywood



youtube.com/polywood



Did you know?


POLYWOOD was the original outdoor furniture made from recycled materials.

Learn more about our story:
genuinePOLYWOOD.com

TOOLS




7/16" wrench
(not included)




1/2" wrench
(not included)

PARTS




A x 24



2.5" Bolt — H516-18X2.5

B x 4



3" Screw — HHL.25X3

O x 24

5/16 X 3/4 OD FLAT WASHER

O x 4

1/4 FLAT WASHER


Something missing?
Call (833) 665-6300

1

Letters face outward

O x 4

5/16 X 3/4 OD FLAT WASHER




Repeat other side

2

O x 4

5/16 X 3/4 OD FLAT WASHER




Repeat other side

3

O x 2


1/4 FLAT WASHER



4

O x 2

1/4 FLAT WASHER




5

A x 2

A x 2

O x 4

5/16 X 3/4 OD FLAT WASHER



6

A x 2

A x 2

O x 4

5/16 X 3/4 OD FLAT WASHER

