

Assembly Instructions



TXA53
Cape Cod
Folding Adirondack

20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

Share your space

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(877) 907-TREX** (8739) or email support@trexfurniture.com

Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

For a quick clean:

Simply wipe down with soap and water.

For a deeper clean:


You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

trexfurniture.com

TOOLS




4mm T-handle hex key (included)



7/16" wrench (not included)

PARTS






1.875" Fine Thread Bolt H.25-20X1.875




2.25" Fine Thread Bolt H.25-20X2.25









Flange Nylon Lock Nut HN.25-20FN





Adirondack Pin - HDPE




Bolts may need to be tapped into the holes if they are a little snug.











NOTE: Please remove pins before folding.



Remove protective plastic film from the logo medallion.

