
POLYWOOD®

Assembly Instructions



NO ASSEMBLY REQUIRED

MS424D100 Acadia Dining Side Chair



20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty: polywood.com/warranty



Cleaning Tips

For a Quick Clean: Simply wipe down with soap and water.

For a Deep Clean:

Wipe on ¹/₃ bleach and ²/₃ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a ¹/₃ bleach and ²/₃ water solution and scrub with a soft bristle brush. Hose down to rinse.

Thank 1 on

Thank you for choosing POLYWOOD! We hope your new furniture helps create a gathering place for you and your loved ones to enjoy for many years to come!

.....



Sign up at: polywood.com/welcome

You'll be the first to hear about new product launches, giveaways, special offers, and more!



If you have questions regarding assembly instructions, warranty claims, or missing parts, please visit our Help Center at help.polywood.com



For assembly tips and videos visit: polywood.com/assembly

Share Your Space

We love to see your furniture at home — share a photo or video and tag us on Instagram or Facebook for your chance to be featured! #polywood





pinterest.com/polywood



facebook.com/polywoodoutdoor

Join thousands of fans in our Outdoor Living Community! facebook.com/groups/polywoodoutdoorliving




Did You Know?

Our long-lasting furniture is made using plastics that could otherwise pollute oceans and overwhelm landfills — and it can also be recycled when the time comes. Better for the planet, better for all.

> Learn more about our story: genuinePOLYWOOD.com

POLYWOOD®

Assembly Instructions



NO ASSEMBLY REQUIRED

MS424D200 Acadia Dining Arm Chair



20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty: polywood.com/warranty



Cleaning Tips

For a Quick Clean: Simply wipe down with soap and water.

For a Deep Clean:

Wipe on ¹/₃ bleach and ²/₃ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a ¹/₃ bleach and ²/₃ water solution and scrub with a soft bristle brush. Hose down to rinse.

Thank 1 on

Thank you for choosing POLYWOOD! We hope your new furniture helps create a gathering place for you and your loved ones to enjoy for many years to come!

.....



Sign up at: polywood.com/welcome

You'll be the first to hear about new product launches, giveaways, special offers, and more!



If you have questions regarding assembly instructions, warranty claims, or missing parts, please visit our Help Center at help.polywood.com



For assembly tips and videos visit: polywood.com/assembly

Share Your Space

We love to see your furniture at home — share a photo or video and tag us on Instagram or Facebook for your chance to be featured! #polywood





pinterest.com/polywood



facebook.com/polywoodoutdoor

Join thousands of fans in our Outdoor Living Community! facebook.com/groups/polywoodoutdoorliving



Did You Know?

Our long-lasting furniture is made using plastics that could otherwise pollute oceans and overwhelm landfills — and it can also be recycled when the time comes. Better for the planet, better for all.

> Learn more about our story: genuinePOLYWOOD.com

20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty: polywood.com/warranty

Cleaning Tips

Simply wipe down with soap

Wipe on ¹/₃ bleach and ²/₃ water

solution with a clean cloth and let it

sit on the lumber for a few minutes

(this will not affect the color). Then,

loosen any dirt and debris that may catch in surface grooves with a soft

bristle brush; hose down to rinse.

Use a pressure power washer (not

exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$

water solution and scrub with a soft

bristle brush. Hose down to rinse.

For a High-Power Clean:

For a Quick Clean:

For a Deep Clean:

and water.

POLYWOOD®

Assembly Instructions

L4D83 Leg Kit

Thank You

Thank you for choosing POLYWOOD! We hope your new furniture helps create a gathering place for you and your loved ones to enjoy for many years to come!

Join the POLYWOOD Community

Sign up at: polywood.com/welcome

You'll be the first to hear about new product launches, giveaways, special offers, and more!


X

We're Always Here For You

If you have questions regarding assembly instructions, warranty claims, or missing parts, please visit our Help Center at help.polywood.com




For assembly tips and videos visit: polywood.com/assembly



PL83-T3L4 Mission 39" X 75"

Dining Table



Join thousands of fans in our Outdoor Living Community! facebook.com/groups/polywoodoutdoorliving



Did You Know?

Our long-lasting furniture is made using plastics that could otherwise pollute oceans and overwhelm landfills — and it can also be recycled when the time comes. Better for the planet, better for all.

> Learn more about our story: genuinePOLYWOOD.com

