Assembly Instructions





Thank you for choosing POLYWOOD!

We hope our furniture helps create a gathering

place for you and your loved ones to enjoy

for many years to come!

Stay Connected

Be the first to hear about new products,

giveaways, and more by signing up for our

email list: polywoodoutdoor.com/subscribe

Watch & Learn

For assembly tips and videos visit:

polywoodoutdoor.com/assembly

Share your space

We love to see where our furniture ends up — snap a pic and tag it on Instagram or Facebook for your chance to be featured on our social channels! #polywood #rethinkoutdoor



facebook.com/polywoodoutdoor



@POLYWOOD



pinterest.com/polywood



youtube.com/polywood







Did you know?

POLYWOOD was the original outdoor furniture made from recycled materials.

> Learn more about our story: genuinePOLYWOOD.com

20-year warranty

View our full warranty: polywoodoutdoor.com/warranty



Having trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at hello@polywoodoutdoor.com or (833) 665-6300



Cleaning tips

For a Quick Clean:


Simply wipe down with soap and water.

For a Deep Clean:


Wipe on 1/3 bleach and 2/3 water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a 1/3 bleach and 2/3 water solution and scrub with a softbristle brush. Hose down to rinse.



8000, 8001, 8002, MOD 30" Table



polywoodoutdoor.com





TOOLS



7/16" wrench (not included)

PARTS









Spring Lock Washer HW.25SL

Something missing? Call (833) 665-6300


1

Spring Lock Washer HW.25SL





x 3





8002