




Assembly Instructions



TXMNB485

Monterey Bay 48" Bench

..... 20-Year Warranty

To view our full warranty, please visit
trexfurniture.com/warranty

..... Share your space

We love to see where our furniture
ends up — snap a pic and share
it with us on Facebook!
facebook.com/trexfurniture

..... Having Trouble?

If you have questions or concerns regarding
assembly instructions or missing parts,
please contact us at **(877) 907-TREX (8739)**
or email support@trexfurniture.com

..... Cleaning Tips

Keep your Trex Outdoor Furniture™
looking brand new:

For a quick clean:

Simply wipe down with soap and water.


For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush


Wipe on solution with your cloth
and let it sit on the lumber for a few
minutes (this will not affect the color).
Then, loosen any dirt and debris that
may catch in surface grooves with a
soft bristle brush; hose down to rinse.

TOOLS



4mm T-handle hex key (included)

PARTS




A x2




1.75" Fine Thread Bolt
H.25-20X1.75

B x14




1.75" Screw — H.27X1.75

C x2




3" Screw — H.27X3

1



Do not fully tighten bolts

2



Do not fully tighten bolts


3

Ensure Fine Thread Bolts are used



1.75" Fine Thread Bolt
H.25-20X1.75

A




4

Ensure Fine Thread Bolts are used




1.75" Fine Thread Bolt
H.25-20X1.75

A



All bolts may be fully tightened



For use on flat, solid, and level surfaces only; not suitable for grass, gravel, or uneven ground.

Trex[®]
Outdoor Furniture