




Assembly Instructions



TXR140 Cape Cod Porch Rocking Chair

..... **20-Year Warranty**

To view our full warranty, please visit
trexfurniture.com/warranty

..... **Share your space**

We love to see where our furniture
ends up — snap a pic and share
it with us on Facebook!
facebook.com/trexfurniture

..... **Having Trouble?**

If you have questions or concerns regarding
assembly instructions or missing parts,
please contact us at **(877) 907-TREX** (8739)
or email support@trexfurniture.com

..... **Cleaning Tips**

Keep your Trex Outdoor Furniture™
looking brand new:

For a quick clean:

Simply wipe down with soap and water.


For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth
and let it sit on the lumber for a few
minutes (this will not affect the color).
Then, loosen any dirt and debris that
may catch in surface grooves with a
soft bristle brush; hose down to rinse.

TOOLS




4mm T-handle
hex key (included)




4mm hex for drill
(included)

PARTS




A x8



3" Screw - H.27X3


B x8




2.5" Screw - H.27X2.5

1

Some may find this easier
to assemble with a friend




2




Partially thread each screw into pilot
holes by hand before fully tightening.


3




4



5



6



! Remove protective plastic
film from the logo medallion.